

***Main Transformer Wiring  
MB I I***

<b>T1 - 413-0003-023 (208, 240, 480VAC, 60HZ)</b>		
<b>INCOMING SERVICE</b>	<b>INPUT SIDE CONNECTIONS</b>	<b>OUTPUT SIDE CONNECTIONS</b>
<b>208 VAC</b>	<b>H1, 1, 8 To H 1 (FU2)</b> <b>H2, 5, 12 To H 2 (FU3)</b> <b>H3, 9, 4 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>
<b>240 VAC</b>	<b>H1, 2, 7 To H 1 (FU2)</b> <b>H2, 6, 11 To H 2 (FU3)</b> <b>H3, 3, 10 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>
<b>480 VAC</b>	<b>2 To 3</b> <b>H1 To H 1 (FU2)</b> <b>6 To 7</b> <b>H2 To H 2 (FU3)</b> <b>10 To 11</b> <b>H3 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>

<b>T1 - 413-0003-024 (600VAC, 60HZ)</b>		
<b>INCOMING SERVICE</b>	<b>INPUT SIDE CONNECTIONS</b>	<b>OUTPUT SIDE CONNECTIONS</b>
<b>600 VAC</b>	<b>H1 To H 1 (FU2)</b> <b>H2 To H 2 (FU3)</b> <b>H3 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>

<b>T1 - 413-0003-025 (415, 380 VAC, 50HZ)</b>		
<b>INCOMING SERVICE</b>	<b>INPUT SIDE CONNECTIONS</b>	<b>OUTPUT SIDE CONNECTIONS</b>
<b>415 VAC</b>	<b>H1, 1 To H 1 (FU2)</b> <b>H 2,1 To H 2 (FU3)</b> <b>H3, 1 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>
<b>380 VAC</b>	<b>H1, 2 To H 1 (FU2)</b> <b>H2, 2 To H 2 (FU3)</b> <b>H3, 2 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>

<b>T1 - 413-0003-026 (200VAC, 50-60HZ)</b>		
<b>INCOMING SERVICE</b>	<b>INPUT SIDE CONNECTIONS</b>	<b>OUTPUT SIDE CONNECTIONS</b>
<b>200 VAC</b>	<b>H1 To H 1 (FU2)</b> <b>H2 To H 2 (FU3)</b> <b>H3 To H 3 (FU1)</b>	<b>X1 To PM-TB5 - 3</b> <b>X2 To PM-TB5 - 2</b> <b>X3 To PM-TB5 - 1</b>

**Note:**

1. All connections are inside T 1.
2. "T 1" is the Main Input Transformer.